



NOTE:
- SEE LOAD DESIGN CHARTS FOR
MAXIMUM OVERHANG.



EAVE DETAILS
PREMIER BUILDING SYSTEMS