

Premier SIP Tape Installation Instructions



Surface Preparation:

All surfaces must be clean, dry and free of dirt, grease, oil and any other contaminants that may interfere with adhesion. Do not apply SIP Tape on the underside of roof panels prior to the installation of the roofing underlayment and final roof covering. Any panel damage must be repaired prior to applying tape. Surfaces temperature of the material Premier SIP Tape is being applied to should be 20 degrees Fahrenheit or warmer.

SIP Tape Installation:

Position tape so that it is centered over the panel joint. SIP Tape should extend a minimum of 3" on either side of the panel joint. Peel off several inches of release backing and press firmly into place. To ensure a tight seal and minimize air bubbles and wrinkles, tape should be pressed into oriented strand board (OSB) at the center, working outward with a smooth motion to the edges. After tape has been applied, it is recommended that a roller or similar tool be used, with firm hand pressure, to remove wrinkles and bubbles and to firmly mate the tape to the OSB surface.

FAILURE TO ADEQUATELY MATE THE TAPE TO THE OSB SURFACE CAN RESULT IN INADEQUATE ADHESION AND FAILURE OF THE SIPS TAPE.

Overlaps (T-Joints):

Wall-to-ceiling or ridge-to-ceiling tape should be applied before ceiling panel joints are taped. Intersections of ceiling panel tape with tape at the ridge or wall should be detailed so that the ceiling panel tape overlaps by a minimum of 3". Press or roll overlaps firmly and carefully to ensure an airtight seal.

End of Roll:

When the end of a roll is reached, install the start of a new roll by overlapping at least 3" of previously installed SIP tape. Press or roll overlaps firmly and carefully to ensure an airtight seal.

Questions:

Contact the Distributor you purchased the SIP Tape from, or your local Premier Representative at 1-800-275-7086.

Website: www.premiersips.com

Email: info@premiersips.com

Toll Free: 800-275-7086