

NOTES:

*SURFACE PREPARATION*

ALL SURFACES MUST BE CLEAN, DRY AND FREE OF DIRT, OIL, AND ANY OTHER CONTAMINANTS. DO NOT APPLY SIP TAPE ON THE UNDERSIDE OF ROOF PANELS PRIOR TO THE INSTALLATION OF THE ROOFING UNDERLAYMENT AND FINAL ROOF COVERING. SURFACE TEMPERATURE OF THE MATERIAL PBS SIP TAPE IS BEING APPLIED TO SHOULD BE 20° F OR WARMER.

*TAPE INSTALLATION*

CENTER TAPE OVER JOINT, REMOVE BACKING AND PRESS FIRMLY INTO PLACE. PRESS FROM THE CENTER OUTWARD TO ENSURE A TIGHT SEAL. AFTER TAPE HAS BEEN INSTALLED REMOVE BUBBLES AND WRINKLES WITH A ROLLER OR SIMILAR TOOL.

*JOINTS OVER BEAMS*

ROLL OUT TAPE CENTERED OVER BEAM PRIOR TO PANEL INSTALLATION AND SECURE WITH STAPLES. AFTER PANELS ARE INSTALLED AND SECURED OVER TAPE, REMOVE BACKING, PRESS FIRMLY INTO PLACE, AND ROLLER JOINT.

*OVERLAPS AND "T" JOINTS*

TAPE FOR PANEL TO PANEL CORNERS AND PANEL JOINTS OVER BEAMS SHOULD BE INSTALLED BEFORE IN PLANE PANEL JOINTS. OVERLAP TAPE A MINIMUM OF 3" AT "T" JOINTS AND WHEN CONTINUING A SEAM TO INSURE AN AIRTIGHT SEAL.

INSTALL RIDGE TAPE FIRST. TAPE BACKING IS PERFORATED TO ALLOW REMOVAL ON EACH SIDE OF BEAM. DO NOT REMOVE BACKING PRIOR TO SIP ROOF INSTALLATION

